October 29, 2012

On the product control panel, press Menu.

- 1. Touch INFORMATION.
- 2. Touch PRINT CONFIGURATION. The configuration page prints.
- 3. Use the firmware date code listed under **Device Information** to determine whether the firmware for your product is compatible.

HP Color LaserJet 4730 MFP

- 1. On the product control panel, press Menu.
- 2. Touch INFORMATION.
- 3. Touch PRINT CONFIGURATION. The configuration page prints.
- 4. Use the firmware date code listed under **Device Information** to determine whether the firmware for your product is compatible.

HP LaserJet M3027, M3035, M4345, M4349, M4555, M5025, M5035, M5039, M9040/M9050, and M9059 MFPs

- 1. On the product control panel, press Administration.
- 2. Scroll to and touch Information.
- 3. Scroll to and touch Configuration/Status Pages.
- 4. Scroll to and touch Configuration Page . The Configuration page prints.
- 5. Use the firmware date code listed in section **Device Information** to determine whether the firmware for your product is compatible.

HP Color LaserJet CM3530, CM4540, CM4730, CM6030, CM6040, and CM6049 MFPs

- 1. On the product control panel, press Administration.
- 2. Scroll to and touch Information.
- 3. Scroll to and touch Configuration/Status Pages.
- 4. Scroll to and touch Configuration Page . The Configuration page prints.
- 5. Use the firmware date code listed in section **Device Information** to determine whether the firmware for your product is compatible.

HP Scanjet 7000 Digital Sender

From the Home screen, touch Administration, touch Information, and then select
Device Configuration Page to view information that is stored internally on the
device.

HP 9250c Digital Sender

1. From the Home screen, touch Configuration/Status Pages, touch Configuration Page, and then touch Show to view information that is stored internally on the device.

Les Olson Company Knowledge Base http://kb.lesolson.com/InstantKB2016/KnowledgebaseArticle50505.aspx